



Preservation & Foreign Object Debris (FOD) Training

Summary

This procedure applies to:

1. Preservation of the product to meet customer requirements
2. The Prevention of Foreign Object Debris

Foreign Object Debris (FOD) - any substance alien to the part or assembly that could cause damage. This includes any material that could be accidentally picked up and included in the packaging. It could also be dirt or chemicals that could get in an assembly and cause damage or deterioration.

Responsibility

1. It is the responsibility of all employees to ensure parts meet requirements by preserving the parts, not use out of date or expired materials, and rotating stock to use oldest items before they expire (First in, First Out - "FIFO")
2. It is the responsibility of management to maintain a list of all materials with a shelf life (expiration date), write clear identifying dates on materials, and dispose of expired materials.
3. It is the responsibility of all employees to see that work areas are cleaned and free of any materials not needed to prevent damage, deterioration, or loss of traceability.

Procedure for Preservation

1. Ensure components are not expired or out-of-date before using.
2. Any material with a shelf life should be checked.
3. Items with a shelf life should have an expiration date listed.
4. Expired material will be placed in the collection area and leaders will submit a waste management form for disposal.
5. Management will determine disposal of expired items.

Procedure for FOD

1. Before starting a job check for any special cleanliness requirements.
2. Clear the work area of any extra material and hardware that could be accidentally used.
3. Clean the work area to prevent damage from dirt or chemicals.
4. Check parts when complete for any unnecessary debris, such as poly, shavings, bolts, nuts, etc. and remove any debris.
5. When finished, package or segregate parts to prevent damage, contamination, or loss of traceability.